BRIGGS & STRATTON®

5550 WATTS

Illustrated Parts List

Questions? Help is just a moment away!

Vous avez des questions? Vous n'avez pas besoin d'aller loin pour trouver de l'aide!

Preguntas? La ayuda es justa un momento lejos!

Call: **Generator Helpline**

Appelez: **Ligne d'assistance de Générateur**

Llame: **Línea Directa del Generador**

1-800-743-4115 M-F 8-5 CT

web: www.briggsandstratton.com

Model / Modèle / Modelo

030253

BRIGGS & STRATTON POWER PRODUCTS GROUP, LLC
JEFFERSON, WISCONSIN, U.S.A.

Manual No. 198171A Revision I (01/25/2006)

EXPLODED VIEW - MAIN UNIT



Copyright © 2005 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form by any means without the express written permission of Briggs & Stratton Power Products Group, LLC.

EXPLODED VIEW - PARTS LIST

Item	Part #	Description
1	J197129GS	KIT, Frame
2	194150GS	KIT, Vibration Mount 45°
3	*	WASHER, M8 Lock
4	190220GS	HOUSING, Engine Adapter
5	*	NUT, Hex M8 - 1.25
6	NSP	ASSY, Alternator (see page 5)
7	*	TPHMS, M8 - 1.25 x 35
8	96796GS	WASHER, M8 Flat
9	67989GS	NUT, M8 Flange Serrated
10	190274BGS	SBHCS, 3/8-16 x 1.0 Lg.
11	47480GS	HHCS, 5/16-24 x 7
12	*	HHCS, M8 1.25 x 25
14	189009GS	BRACKET, Muffler
15	695398	GASKET, Exhaust
16	*	HHCS, M6 1.0 x 12
17	189008GS	MUFFLER
18	*	SHCS, 5/16 - 18 x 3/4"
19	83083GS	SCREEN, Spark Arrest
20	B4986GS	DECAL, Ground, Green
21	194153GS	KIT, Vibration Mount
22	86494GS	SCREW, Wing, M6 1 x 16
23	86292GS	SCREW, 10-16 x 3/4, Self Drill
24	192793GS	SHIELD, Heat
25	191190GS	CAP
26	74908GS	SCREW, M5-0.8 x 10 Taptite
28	*	WASHER, Flat 1/2
29	94929GS	SCREW, Hex Wash HD
30	226846	BRACKET, Oil Fill Tube
31	196830GS	DECAL, Hot Muffler
34	195422GS	COVER, Bearing Carrier w/ Cap
35	199838GS	KIT, Hose Fuel w/ Clamps (cut to fit)
37	192376GS	SCREW, 12 - 24 x 1/2 THD Forming
40	192553GS	KIT, Vibe Mount
41	192980GS	KIT, Valve Tank
44	196181GS	ASSY, Tank, Fuel (Includes Items 41, 50, 51 & 52)
45	189420GS	CAP, Fuel Gauge
48	195373GS	WIRE, Ground
49	193548GS	KIT, Wheel
50	188333GS	DECAL, Fuel Tank
51	194799GS	DECAL, Danger
52	189235GS	DECAL, Start Instructions
53	192050GS	E-RING
55	197798GS	DECAL, Shut-Off, Fuel
56	J194907GS	HANDLE
57	189456GS	KIT, Handle Fastening
58	190355GS	ASSY, Control Panel (see page 4)
59	*	NUT, Palnut 3/16"
60	189117GS	QUICK CONNECT, Fuel, 1/4 Barb
61	192695GS	QUICK CONNECT, Fuel, 1/4 Barb
63	189114GS	KNOB, Fuel Tank Hold Down
72	192480GS	DECAL, Warning, Fuel Line Disconnect
900	§	ENGINE

Parts Not Illustrated

BB3061GS	BOTTLE, Oil
43438GS	PLUG, 250V, 30A
MS5242	MANUAL, Engine
198171GS	MANUAL, Operator's
100031	STABILIZER, Fuel
199384GS	DECAL, Family, CA EVP
198419GS	KIT, Decals Srv

* - Items without part numbers are common fasteners and are available at your local hardware store.

§ - Contact Engine Manufacturer

EXPLODED VIEW AND PARTS LIST - CONTROL PANEL



Item	Part #	Description
1	195112GS	KIT, Control Panel Lid
2	188889GS	CONTROL PANEL, Compact
6	68759GS	OUTLET, 120V, 20A, Duplex
7	*	NUT, Palnut, Pushnut, 5/32
8	84198GS	CAP, Breaker, Circuit
9	75207GS	BREAKER, Circuit
10	43437GS	OUTLET, 120/240V Locking, 30A
11	*	NUT, Palnut, Pushnut, 3/16
12	*	SCREW, Phillips, Head 3.5 x 18
13	93857GS	BAR, Retaining
14	188890GS	COVER, Back, Control Panel
15	82308GS	SCREW, Self Tapping, STC 3 x 18
16	22694GS	HOUSING, Receptacle
17	*	SCREW, Phillips, 3.5 x 14

* - Items without part numbers are common fasteners and are available at your local hardware store.

EXPLODED VIEW AND PARTS LIST - ALTERNATOR



Item	Part #	Description
1	186059GS	ADAPTER, Mounting, Alternator
2	191043GS	ASSY, Rotor (Includes Item 12)
3	191042AGS	STATOR
4	186060GS	RBC, with O-Ring (p/n 189197GS)
5	86308CGS	HHCS, M6 - 1.0 x 130 SEMS
6	91825GS	ASSY, Holder, Rectifier/Brush
7	66849GS	TAPTITE, M5 - 0.8 x 16
8	22694GS	RECEPTACLE, 6 pin
9	81917GS	PIN, Roll, 4mm x 10
10	193428AGS	ASSY, Wire, Ground
11	194274GS	HARNESS, Wire, Power
12	65791GS	BEARING